

POIN2 Chromebook 11

Quick Start Guide

Skip the waiting. Forget the set-up. Leave the manuals behind. Go online creating, sharing and enjoying. Because everything is faster and easier on a Chromebook.

google.com/chromebook

Check the components

Your Chromebook comes with:

- AC adaptor and Power cord/cable
- Documentation, including this Quick Start Guide and a Standard Limited Warranty



Right Side View



Micro SD USB Audio


Left Side View



DC-In USB HDMI

Getting started

- 1 Start up your Chromebook.** Insert power cord for the first time use of your Chromebook. To turn on the device, simply open the lid or press the power button.
- 2 Select a network.** Nearby networks will be displayed automatically. Simply choose network name you would like to connect.
- 3 Sign in with your Google Account.** Enter your Google Account username and password and click "Sign in". If you don't have a Google Account, click Create a Google Account on the right side of the sign-in box or browse as Guest.
- 4 Start Browsing.** Once you sign in, you're instantly on the web and automatically signed in to the Google services you use. To get started, type a website or a search query into the address bar.
- 5 Chrome Web Store.** Thousands of free games, entertainment, and productivity apps. chrome.google.com/webstore
- 6 Log out/Power off.** Open the notification panel located on the bottom right. Click "Log out" to end your current session, or click Power Symbol "⏻" to shut down the device.
- 7 Get to know your Chromebook.** For more information on how to master the Chromebook essentials, please visit the online getting started guide.: google.com/chromebook/knowyourchromebook



< Poin2 Chromebook Function Keys >